



Tasman & Milford Pre Delivery Guide

Paramount Pools would like to Thank you for purchasing one of our New Zealand Made Paramount Spas.

Once you have selected the area you would like your spa there are a few things you need to ensure.

- Prior to installation of your spa, your electrician will need to arrange an adequate 15amp, 3 pin plug power supply for your spa.
- Please allow a 600mm clearance around your spa to access equipment
- Do not put your spa on any soft surface such as grass, sand, pebble or dirt as this may place undue stress on your spa therefore voiding your warranty.

Placing on a concrete slab

A reinforced concrete slab of at least 100mm (4") thick is a suitable foundation for your spa;. You must ensure this base is an even, level surface free from cracks or hollows. It's preferable for the slab to extend at least 200mm outside the spa dimensions for stability.

Placing on timber decking

Paramount Pools recommend that you consult a structural engineer to ensure that your decking is capable of safely and adequately supporting the full weight of your spa when in use. Should you wish to surround your spa with decking, we suggest that you install it on a concrete slab (as above) then build the deck to surround your spa.

Please note

- It is the owner's responsibility to ensure correct installation of the spa.
- If you are unsure of any aspect of the site preparation please consult your Paramount Store for clarification



- Paramount Pools will take no responsibility for the installation of your spa
- Whether choosing a concrete slab or timber decking to support your spa pool, Paramount Pools strongly recommend the use of a licensed contractor.
- The connection must be completed by a qualified electrician who must supply an Electrical Safety Certificate as this could be asked for upon warranty requests.